


Color Pro™ Support

Rear Bezel



- | | | |
|-----|----------|------------------------------|
| 1. | 99350027 | Bezel, Rear |
| 2. | 99310265 | Label, Rear Bezel Left |
| 3. | 99310331 | Label, Rear Bezel Right |
| 4. | 90409060 | Cable Assy. XLR 5 Pin Female |
| 5. | 90409059 | Cable Assy. XLR 5 Pin Male |
| 6. | 90711007 | Screw, Phil Flat #4 x 3/8 |
| 7. | 80470196 | AC Line Cord Assy. |
| 8. | 90703050 | Nut, Strain Relief Locking |
| 9. | 99080062 | Plate, Adjustable Lamp Mount |
| 10. | 99410065 | Label, Lamp Plate |
| 11. | 85000129 | Plate, Lamp Socket Slide |
| 12. | 99150019 | Lamp Socket |
| 13. | 90706079 | Washer |
| 14. | 90705026 | Thumbscrew, M3 x 20 |
| 15. | 80470164 | Wire, Ground Lamp Plate |
| 16. | 90703005 | Nut, 6 - 32 Keps Nut |