



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

DW Fresnel Parts List

| Item | Description |
|-----------------|--|
| 50204040060 | PCB0211B DMX SOCKET FOR DLED TRI BRICK, |
| Z-500/GMA | 10A 250V AC MIDGET FUSE HOLDER FOR DESIGN SPOT 250 |
| 50101017845 | GEL FRAME FOR DW FRESNEL |
| 50101018207AA0 | SOI BRACKET FOR DW FRESNEL, DW PROFILE |
| 50102090450 | FOCUS KNOB FOR DW FRESNEL |
| 50102090453C | WASHER FOR DW FRESNEL |
| 501990100190J0 | EYE HOOK FOR DW FRESNEL, EPV15 |
| 50202013451V100 | PCB08830C DISPLAY PCB FOR DW FRESNEL (V1.0.0) |
| 50202013451V110 | PCB08830C DISPLAY PCB FOR DW FRESNEL (V1.1.0) |
| 50202013452V100 | PCB10570A PCB FOR DW FRESNEL (V1.0.0) |
| 50202013452V110 | PCB10570A DIMMER, STROBE PCB FOR DW FRSNEL (V1.10) |
| 50202013464V100 | PCB08830C DISPLAY PCB FOR DW PROFILE |
| 50203012368 | PCB0636A CONVERTER PCB FOR DW FRESNEL, DW PROFILE |
| 50301011001 | SIDE COVER 1 FOR DW FRESNEL |
| 50301011002 | SOI SIDE COVER 2 DOR DW FRESNEL |
| 50301011003 | BACK COVER FOR DW FRESNEL |
| 50301011005 | HANDLE FOR DW FRESNEL, DW PROFILE |
| 50301011006 | DISPLAY KNOB FOR DW FRESNEL, DW PROFILE |
| 50401990012 | FRESNEL LENS FOR DW FRESNEL |
| 60106040157 | BRACKET KNOB FOR DW FRESNEL |
| 60202020002 | RUBBER FOOT FOR E SPOT LED II, DW FRESNEL |
| 60301020031 | LENS FOR DW FRESNEL |
| 60405030135 | SOI LED MODULE FOR DW FRESNEL |
| 60411040175 | 48V-8.3A POWER SUPPLY FOR DW FRESNEL, DW PROFILE |
| 60416020047 | 24VDC FAN FOR DW FRESNEL, DW PROFILE |
| 60418010001 | 3 PIN 10A 250V POWER SWITCH FOR DW FRESNEL, DW PROFILE |
| ESD0008-B | BLUE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60 |
| P-CON CABLE 12G | 12AWG POWER CABLE W/ POWERCON FOR PZ720A |
| Z-FUSE/GMA-5A | 5 AMP GMA SINGLE FUSE |