



## S-500 & S-500XL

# IMPORTANT INFORMATION PLEASE READ BEFORE USE

### AIR HOSE PLACEMENT IN ROAD CASE

In order to prevent any operation issues, the complete length of the included Air Hose (S-500 = 10m | S-500XL = 20m) **MUST** be removed and neatly coiled back inside the road case before each use. This will prevent any severe bending, which can cause a backup during operation and may cause the hose to burst, especially when not fully extending the hose outside the road case.

