


Cyberlight

Lower Housing/ Fans



1.	80070243	Panel, Extrusion Rear Fan
2.	80070214	Plate, Rear Fan
3.	80070243	Panel, Extrusion Rear Fan
4.	80070238	Plate, Rear Fan End
5.	80270054EF	Fan, Rear Assy.
6.	80270054EF	Fan, Rear Assy.
7.	99260070	Plate, Fan Heat Block
8.	90410066	Latch, Door Plastic
9.	80070225	Plate, Door End
10.	80070241	Panel, Extrusion Door Side
11.	80070241	Panel, Extrusion Door Side
12.	80070228	Plate, Door Cover
13.	80070225	Plate, Door End
14.	80070227	Plate, Front Fan End
15.	80070244	Panel, Extrusion Front Fan
16.	80070244	Panel, Extrusion Front Fan
17.	80070231	Plate, Front Fan
18.	80270053EF	Fan, Front Assy.

Additional Parts Not Listed:

	99410050	Label, Door
	90409024	Cable, Safety With Clip
	80320009	Door Assembly
	99310146	Label, Caution Fan

99310116	Label, Do Not Touch
----------	---------------------

[Cyberlight Exploded Diagrams Main Page](#)