

Pic.No. 10-0054-00-00-00					
S/R	PART NUMBER	DESCRIPTION	PART NAME	QTY	REMARK
8	80105010015	TB05-03-M8*32	plastic head screw	2	
7	80105010021	TB05-003-M6*12	plastic head screw	2	
6	80102011046BA	LB-60L-08	right bracket	1	
5	80102011044BA	LB-60L-05	left bracket	1	
4	80102011037CA	LB-12-15	right handle	1	
3	80102011036CA	LB-12-14	left handle	1	
2	80101110047AA	LB-12-09	handle washer	2	
1		10-0054-01-00-00	head assembly	1	

Pic.No. 13-0050-01-00-00					
S/R	PART NUMBER	DESCRIPTION	PART NAME	QTY	REMARK
17	203010530	PCB0221A	PCB assembly	1	
16	80105050003	lib_qlock-02	quick lock washer	2	
15	80105050002	lib_qlock-01	quick lock	2	
14	2012400240A	LB12HP-01B-01	main bracket I	1	
13	80102012393AC	LB12HP-01A-04	PCB bracket	1	
12	80201050024	LB-12T-01C-02	plastic washer	1	
11	802010802300D	LB-12T-01C-01	front cover	1	
10	2012400300A	LB-12T-01B-01	main bracket III	1	
9	801020125410C	LB-12T-01A-08	power bracket	1	
8	801020125400A	LB-12T-01A-07	fan bracket	1	
7	801020125390A	LB-12T-01A-06	side board	1	
6	80102012445AA	LB-12T-01A-05	pressing plate	1	
5	801020124410A	LB-12T-01A-01	side board	1	
4	80412020025	KDE2406PTV1. MS. A. GN	DC fan	1	
3	80407040028	ESM-U60S12	electronic transformer	1	
2		10-0054-01-02-00	back cover assembly	1	
1		10-0054-01-01-00	washer board assembly	1	

Pic.No. 10-0054-01-01-00					
S/R	PART NUMBER	DESCRIPTION	PART NAME	QTY	REMARK
10	80302070004	TY-A45A-L3 45°	Lens	4	

9	80105040163	TB05-023-M4X15	screws	1	
8	203010537	LJB0013A	PCB assembly	4	
7	801010400250	lib_screw-01-th	columnar spring	1	
6	80105050004	lib_qlock-03	quick lock holder	2	
5	801011100890	LIB-SCREW-01-ZU0-A	M4 screw holder	1	
4	80102012444AA	LB-12T-01A-04	lens pressing plate	1	
3	80102012443AC	LB-12T-01A-03	reflector fixing board	1	
2	80102012442AC	LB-12T-01A-02	washer	1	
1	80416020010	KSD020-1A 250V 15A 90°C	thermostat	1	

Pic.No. 10-0054-01-02-00

S/R	PART NUMBER	DESCRIPTION	PART NAME	QTY	REMARK
10	80414090008	φ 11. 4*6. 8	switch cover	4	
9	80408040006	SS-8B-VDE-NEW-4. 8	power holder	1	
8	80414010002	R9-22A	power switch	1	
7	207050038	PCB0211B_A00	XLR socket ASS'Y	1	
6	203010521	PCB0210A	PCB assembly	1	
5	80104090007	M6*12	Soft rope ring	1	
4	801020123910A	LB12HP-01A-02-A	back board	1	
3	80102011039AA	LB-12-17	strengthen washer	1	
2	80408040005	C4RF-2004-C-4. 8	power socket	1	
1	80416030015	5T 2A 250V	fuse	2	