

DLED 60 Strip WA

DMX CHANNEL TRAITS

4 Channel Mode (default): This chart details a simple layout of the DMX channel assignment in 4-channel mode.

DMX channel's functions and their values (4 Channel Mode - Default):	
<u>Channel 1 - White:</u>	
0-255	White (0 = Black, 255 = 100% White)
<u>Channel 2 - Amber:</u>	
0-255	Amber (0 = Black, 255 = 100% Amber)
<u>Channel 3 - Strobe:</u>	
0	Normal Operation
1~95	Strobe effect slow to fast
96-127	No function
128-159	Pulse effect in sequences
160-191	No function
192-223	Random strobe effect slow to fast
224-255	No function
<u>Channel 4 – Master Dim</u>	
<i>This channel has two functions depending on the operating mode. When running the built-in programs this channel will control the program speed.</i>	
0-255	Dimming (0%-100%) ~ Normal Operation
0-255	Speed (min to max) ~ When running built-in programs on channel 4

2 Channel Mode (user setting via dipswitch 12): This chart details a simple layout of the DMX channel assignment in 2-channel mode.

DMX channel's functions and their values (2 Channel Mode):	
<u>Channel 1 - White:</u>	
0-255	White (0 = Black, 255 = 100% White)
<u>Channel 2 - Amber:</u>	
0-255	Amber (0 = Black, 255 = 100% Amber)

