


A
B
C
D
E



SPARE PARTS OF F-7

- | | |
|----------------------|---------------------------|
| ① F-7-H | Heater |
| ② C04135001 | Thermostat |
| ③ C01023000 | Copper Threaded Spacer |
| ④ F-7-CP | Brass Tube (Group) |
| ⑤ F-7-PCBS | Optical Iiquid Sensing |
| ⑥ W-DMXR | Antenna & Cable |
| ⑦ C04101400 | Breaker |
| ⑧ C04000100 | Rocker Switch/Power |
| ⑨ C04312600 | Power socket (Inlet) |
| ⑩ C04311900 | Power socket (Outlet) |
| ⑪ F-7-PCBD3 | P.C Board DMX 3Pin |
| ⑫ F-7-PCBD5 | P.C Board DMX 5Pin |
| ⑬ C04112000 | FUSE |
| ⑭ F70001000 | Steel Case/Modified Board |
| ⑮ W-DMX-PCB | W-DMX Board |
| ⑯ F-7-PCB | Main P.C Board |
| ⑰ F70001300 | PCB Bracket |
| ⑱ F70001900 | Steel Case/Lower Base |
| ⑲ F70001400 | Steel Case/Front |
| ⑳ F-7-FAN | FAN(Group) |
| ㉑ C02006000 | Plastic Nozzle |
| ㉒ F70000H00 | Steel Case/Cover |
| ㉓ F-7-P(PA0EX5A10) | Pump (Group) |
| ㉔ F-7-LUS(LUS3A052B) | Solenoid Valve |
| ㉕ F70001201 | Solenoid Valve Bracke |
| ㉖ F-7-PA(PA1A0381P) | Air Pump |
| ㉗ F30000301 | Air Pump Bracket |
| ㉘ F-7-PCBC | Control P.C Board |
| ㉙ F-7-TKC(TKC6A00AA) | Tank Cover |
| ㉚ F-7-TK(TK0705000) | Tank |
| ㉛ F-7-PC(PCA014201) | Power Cord & Plug |
| ㉜ F-7-N | Nozzle (Group) |
| ㉝ FF-7 | Flight Case |
| ㉞ F-7-CS | Brass Tube (Group) |



Antari Lighting And Effects Ltd.