


SPARE PARTS OF HZ-500J(100V)

- | | | |
|---|----------------|----------------------------------|
| 1 | HZ050LH00 | Steel Case/Left Side |
| | HZ050RH00 | Steel Case/Right Side |
| | HZ0500L00 | Steel Case/Base |
| | HZ0500103 | Steel Panel |
| | HZ0500200 | Tank's Sink |
| | HZ0500301 | Steel Plate |
| | HZ0500400-ATR1 | Plastron/Window |
| | HZ0501H04-ATR1 | Left Upper Steel Case/Cover |
| | HZ0502H01 | Right Upper Steel Case/Cover |
| 2 | C000107B0 | Copper Connector |
| | C01013000 | M8*12LScrew |
| | C01H05101 | Tank's Cap Ring |
| | C01H05200 | Tank's Cap |
| | C01H05301 | Tank's Cap Fixer |
| | C02000500 | Magnet |
| | C02000700 | L.C.D |
| | C02005100 | Senser Housing |
| | C02005300 | Handle |
| | C02009000 | Rubber keypad |
| | C02018200 | Shockproof Foot |
| | C02011101 | Rubber Cap |
| 3 | C04000100 | Rocker Switch |
| | C04111600 | Fuse (T7A/120V) |
| | C042046A0 | Fan |
| | C04205200 | Guardrail |
| | C050356J1 | Cable |
| | C15HZ50AD | Power Inlet Socket & Fuseholder |
| | D01004000 | M3*8L Screw |
| | D01101000 | M4*8L Screw |
| 4 | FHZ-500 | Fly Case |
| | HZ-500J-C | Air Compressor & Start Capacitor |
| | HZ-500-PCBC | Control P.C Board |
| | HZ-500-PCBD5 | DMX P.C Board |
| | HZ-500-MS | Senser P.C Board Group |
| | HZ-500-PCBP | Main Power P.C Board |
| | HZ-500-TK | Vapour Tank&Cap(Group) |
| | HZ-500-VN | Vapour Tank Nozzle |



Antari Lighting And Effects Ltd.

育安照明企業股份有限公司

版次	01
HZ50020121003	