



SPARE PARTS OF ICE-101(120V)

ICE000H00	Steel Case/Cover	ICE001500	PCB Cover	C04003500	Rocker Switch/Volume	D01105000	E Ring
ICE000L00	Steel Case/Base	C00007000	Filter(4L)	C04118400	Fuse (T10A)	ICE-101-CP	Copper Tube(Group)
ICE000I00	Steel Case/Back Panel	C00007100	Filter(6L)	C042042A0	Fan	ICE-101-FS	Fluid Sensor W/ PCB
ICE000400	PCB Base	B06506000	P.C Board	C04205200	Guardrail	ICE-101-H	Heater (Group)
ICE000500	Vent	B06507000	P.C Board(Low Fluid Sensor)	C04505600	Temperature sensor	ICE-101-P	Pump (CM12040A0)
ICE000600	Front Panel /Left	C01013000	M8x12L Screw	C050116A0	Cable & Plug	ICE-101-PW	Water Pump(CM12031A0)
ICE000700	Front Panel /Right	C02003500	Foot	C0DNG1100	Trundle	ICE-101-PCB	P.C Board(B06523000)
ICE000800	Back Cover	C02006800	Gasket	C15ICE00A	Control Inlet Socket 4Pin(XLR)REMOTE	(include C1CF54000	+C1CF71600)
ICE000900	Handle/Front	C02013500	Handle	C15ICE00B	Control Outlet Socket 4Pin(XLR)REMOTE	ICE-101-TF	Temperature Fuse
ICE001000	Outtake	C02013800	Chabber Knob	C15ICE00C	Control Inlet Socket 3Pin(XLR)DMX	ICE-101-TK	Tank (C02002400)
ICE001100	Side Panel/Left	C02042500	Pu Tube (ø4)	C15ICE00D	Control Outlet Socket 3Pin(XLR)DMX	ICE-101-TKC	Tank's (Group)
ICE001200	Side Panel/Right	C02064000	Pu Tube (ø6)	C15ICE0A1	Power Inlet Socket & Fuseholder	Z-8	Wired Remote Controller
ICE001300	Ice Plate	C03ICE100	SBR	D01101000	M4x8L Screw		
ICE001400	Chamber Partition	C04000100	Rocker Switch/Power	D01102000	M6x10L Screw		