



SPARE PARTS OF M-4

- | | |
|-----------------|------------------------|
| ① M0070LH00-M4 | Steel Case/Left Cover |
| ② M00400101 | Steel Case/UP Base |
| ③ C01001000 | Screw |
| ④ M00700300-M4 | Steel Case/Tank Cover |
| ⑤ M-4-LUS | Solenoid Valve (Group) |
| ⑥ M-4-CP | Brass Tube |
| ⑦ M-4-H | Heater |
| ⑧ C02013200 | Handle |
| ⑨ D04012000 | Snap Bushing |
| ⑩ M0040RH00 | Steel Case/Right Cover |
| ⑪ M-4-P | Pump (Group) |
| ⑫ M-4-TKC | Tank Cover |
| ⑬ M-4-TK | Tank |
| ⑭ M-4-PCBC | Control P. C Board |
| ⑮ M-4-PCBD3 | P. C Board DMX 3Pin |
| ⑯ M-4-PCBD5 | P. C Board DMX 5Pin |
| ⑰ C04101400 | Breaker |
| ⑱ C04312600 | Power Inlet |
| ⑲ WTR-30A | Wireless Receiver |
| ⑳ M00700L00-M41 | Steel Case/Down Base |
| ㉑ M-4-PCB | Main P. C Board |
| ㉒ M-4-PC | Power Cord & Plug |

文管中心
2014.10.22
發行



Antari Lighting And Effects Ltd.
育安照明企業股份有限公司

版次 02
M4-20141017-01