


A B C D E



SPARE PARTS OF Z-1000 (120V)

Z100000L	Steel Case/Base	C00210	Copper Tube	C04084	Fuse (T10A/125V)
Z100000H	Steel Case/Cover	C02001	Magnetized Rubber	C05016	Cable & Plug
Z10000HB	Yoke	C02019	Tank	C05026	Cable For Remote Control
B06116	P.C Board	C02031	Foot	C15Z10-1	Temperature Fuse
BOX004	Controller Case	C02135	Handle	C15Z10-2	Power Inlet Socket & Fuseholder
C00004	Buckle	C02136	Tightening Screw	D01003	P.C.B Fastening Screw
C00005	Trestle	C02045	Washer	D01101	M4x8L Screw
C00010	Nozzle Plate	C04001	Rocker Switch/Power	D02150	Pu Tube (Ø4)
C00015-1	Heater Core	C04005	Continuous Switch/Red	D04022	Ring Bushing
C00057	Copper Nut	C04006	Timer Switch/Yellow	D04103	P.C.B Fastening Pin
C00058	Copper Nut Insert	C04007	Manual Switch/Green	F2800001	Binder
C00065	P.C.B Fastening Screw Collar	C04057	Temperature Sensor	M12010	Pump
C00070	Filter	C04062	Knob	U12010	Heater Element
C00072	Adaptor With Nut	C04063	Pilot Lamp/Red	Z-1000-H	Heater (group)
C01013	M8x12L Screw	C04064	Pilot Lamp/Green	Z-4 Unit	Wired Remote Controller
C01014	M8 Screw	C04065	Pilot Lamp/Yellow		

Antari Lighting And Effects Ltd.