



SPARE PARTS OF Z-1200IIX(120V) Rev:2.1

Z1202LH00	Side Panel/Left	C02045000	Washer
Z1202RH00	Side Panel/Right	C02014300	Handle
Z1202L01	Steel Case/Base	C04000100	Rocker Switch/Power
Z1202H00	Steel Case/Cover	C04101400	Breaker (120V/15A)
Z12020100	Binder	C04107400	Thermostat/ 140C
C00000100	Nozzle Plate	C045E0400	Temperature Sense
C00007000	Filter	C050101A0	Cable & Plug
C00012700	Adaptor With Nut	C15Z1200A	Control Outlet Socket (4Pin XLR for remote)
C01013000	M8x12L Screw	C15Z1200B	Control Inlet Socket (4Pin XLR for remote)
C01014000	M8 Screw Safety Ring	D01004000	M3x8L Screw
C02003500	Foot	D01101000	M4x8L Screw
C02042500	PU Tube		

Z-1200II-CP	Copper Tube (Group)
Z-1200IIX-N	Nozzle
Z-1200IIX-H	Heater Group(C00002600)
Z-1200II-HB	Hanging Bracket Set
Z-1200II-P	Pump (CM12070A0)
Z-1200II-PCB	Main PC Board (B066070A0) included IC(CICF71600)
Z-1200II-PCBD	DMX PC Board (B06606000) included IC(CICF71600)
Z-1200II-TK	Tank (C02001400)
Z-8	Wired Remote Controller

