



SPARE PARTS OF Z-1500II (120V)

Z1502LL00	Steel Case/Base	C02064000	Pu Tube (Ø6)	Z-1500II-H	Heater (Group)
Z15020H00	Steel Case/Cover	C04000100	Rocker Switch/Power	Z-1500II-P	Pump (CM12070A0)
Z1502LH00	Side Panel/Left	C04101400	Breaker(120V/15A)	Z-1500II-PCB	P.C Board (B066080A0)
Z1502RH00	Side Panel/Right	C04109000	Thermostat		included IC(CICF71600)
Z15020L00	Steel Case/Base	C045E0400	Temperature Sense	Z-1500II-PCBD3	P.C Board DMX 3Pin(B06605A00)
C00007100	Filter 6L	C050101A0	Cable & Plug	Z-1500II-PCBD5	P.C Board DMX 5Pin(B06605B00)
C01013000	M8x12L Screw	C15Z1500J	Control Outlet Socket(5Pin XLR for Remote)	Z-1500II-TK	Tank(C02001800)
C02003100	Foot	D01101000	M4x8L Screw	Z-1500II-TKC	Tank's Cap (Group)
C02006401	Power Cord Support	Z-1500II-CP	Copper Tube (Group)	Z-20	LCD Wired Remote Controller
C02008300	Nut				
C02014300	Handle				



Antari Lighting And Effects Ltd.
 育安照明企業股份有限公司