



SPARE PARTS OF Z-800II (120V)

Z80200L00	Steel Case/Base	C02003100	Foot	Z-800II-H	Heater Group(CU12080A0)
Z80200H00	Steel Case/Cover	C02003600	Nozzle Cover	Z-800II-HL	Handle(C02014300+C04503600)
Z8020LH00	Side Panel/Left	C02014900	Silcon Tube	Z-800II-P	Pump(CM12071A0)
Z8020RH00	Side Panel/Right	C04003100	Rocker Switch/Power(Red)	Z-800II-PCB	P.C Board(B066040A0)
C00005201	Nozzle	C04119200	Fuse (T7A)		included IC(CICF67500)
C00005600	Copper Insert	C04112000	Fuse Holder(5x20)	Z-800II-TF	Temperature Fuse(C045E0700)
C00011700	Silicon Nut Insert	C045E0100	K Type Cable	Z-800II-TK	Tank(C02000800)
C01008000	Copper Screw(Rear)	C045E0300	Remote Controller Holder	Z-800II-TKC	Tank's Cap(C020029C0)
C01009000	Copper Screw(Front)	C050102A0	Cable & Plug	Z-10	Wired Remote Controller
C01013000	M8x12L Screw	D01030000	M3x6L Screw(Sliver)		
C02001000	Fluid Tank Seal	D01101000	M4x8L Screw		



Antari Lighting And Effects Ltd.