







A B C D E

1
2
3
4
5
6
7
8



SPARE PARTS OF Z-Stream (120V)

F28000L01-I28	Steel Case /Base	C02064000	Pu Tube (6X4)	I-280II-H	Heater Group
I28000H00-ELA	Steel Case/Cover	C04112000	Fuse Holder	I-280II-P	Pump
C02013500	Handle	C04118400	Fuse (F10A/120V)	I-280II-PCB	P. C Board
C04107400	Temperature switch	C045E0501	Temperature Sensor	I-280II-TK	Tank
C02001300	Tank	C050101A0	Power Cord & Plug	I-280II-TKC	Tank's Cap(Group)
C02003500	Foot	C15I280A4	Temperature Fuse	I-280II-CP	Copper Tube
C020029C0	Tank's Cap	D01101000	M4x8L Screw	VR-1T	Wired Remote Controller
		D04103000	Spacer Support		