

# **Elation Design Wash 575E**

## **Channel 1 – Pan Movement 8bit:**

## **Channel 2 – Pan Fine**

## **Channel 3 – Tilt Movement 8bit:**

## **Channel 4 – Tilt Fine**

## **Channel 5 - Color Wheel 1:**

0-13	Open / white
14-27	Color 1
28-41	Color 2
42-55	Color 3
56-69	Color 4
70-83	Color 5
84-97	Color 6
98-111	Color 7
112-127	Color 8
128-187	Forwards rainbow effect from fast to slow
188-195	No rotation
196-255	Backwards rainbow effect from slow to fast

## **Channel 6 - Cyan Color Wheel:**

0-255	Cyan (0-white, 255-100% Cyan)
-------	-------------------------------

## **Channel 7 - Magenta Color Wheel:**

0-255	Magenta (0-white, 255-100% magenta)
-------	-------------------------------------

## **Channel 8 - Yellow Color Wheel:**

0-255	Yellow (0-white, 255-100% Yellow)
-------	-----------------------------------

## **Channel 9 - Effect wheel**

0-3	Open / white
4-127	Beam shaper indexing
128-189	Forwards rainbow effect from fast to slow
190-193	No rotation
194-255	Backwards rainbow effect from slow to fast

### **Channel 10 – Seamless Zoom**

0-255 Zoom adjustment from small to big

### **Channel 11 - Shutter, Strobe**

0-31 Shutter closed  
32-63 No function (shutter open)  
64-95 Strobe effect slow to fast  
96-127 No function (shutter open)  
128-159 Pulse-effect in sequences  
160-191 No function (shutter open)  
192-223 Random strobe effect slow to fast  
224-255 No function (shutter open)

### **Channel 12 – Dimmer intensity**

0-255 Intensity 0 to 100%

### **Channel 13 - Color Macros - CMY and Color Wheel**

0-7	Off	128-135	Macro16
8-15	Macro1	136-143	Macro17
16-23	Macro2	144-151	Macro18
24-31	Macro3	152-159	Macro19
32-39	Macro4	160-167	Macro20
40-47	Macro5	168-175	Macro21
48-55	Macro6	176-183	Macro22
56-63	Macro7	184-191	Macro23
64-71	Macro8	192-199	Macro24
72-79	Macro9	200-207	Macro25
80-87	Macro10	208-215	Macro26
88-95	Macro11	216-223	Macro27
96-103	Macro12	224-231	Macro28
104-111	Macro13	232-239	Macro29
112-119	Macro14	240-247	Macro30
120-127	Macro15	248-255	Random CMY

### **Channel 14 - Speed Of CMY And Dimmer:**

0-255 Speed Max  $\rightarrow$  Min

### **Channel 15 - Speed pan/tilt movement**

0-225 max to min speed  
226-235 Blackout with movement

- 236-245 Blackout with all wheel changing
- 246-255 No function

**Channel 16 – Lamp on/off, reset, internal programs**

- 0-19 Color change normal
- 20-39 Color change to any position
- 40-59 Lamp on
- 60-79 Lamp switch off
- 80-84 All motor reset
- 85-87 Scan motor reset
- 88-90 Colors motor reset
- 91-93 No function
- 94-96 Shutter & Dimmer motor reset
- 97-99 Other motor reset
- 100-119 Internal program 1 (scene1~8 of EEPROM)
- 120-139 Internal program 2 (scene9~16 of EEPROM)
- 140-159 Internal program 3 (scene17~24 of EEPROM)
- 160-179 Internal program 4 (scene25~32 of EEPROM)
- 180-199 Internal program 5 (scene33~40 of EEPROM)
- 200-219 Internal program 6 (scene41~48 of EEPROM)
- 220-239 Internal program 7 (scene49~56 of EEPROM)
- 240-255 Music Control (scene of Program 1)