

Installing the DL.2 Roadcase Label

To prevent damage to the front window glass, the DL.2 fixture needs to be loaded correctly into the roadcase.

Orient the enclosed label in the roadcase as shown in Figure 1.




Figure 1: Orientation for fixture positioning label.

HIGH END SYSTEMS[®]



P/N 60600276

Installing the DL.2 Roadcase Sticker

To prevent damage to the front window glass, the DL.2 fixture needs to be loaded correctly into the roadcase.

Orient the enclosed sticker in the roadcase as shown in Figure 1.



Figure 1: Orientation for fixture positioning sticker.

HIGH END SYSTEMS®



P/N 60600276