

ELAR 216 PANEL DW_DMX Channel

DMX channel's functions and their values :

| Mode/Channel | | Value | Function |
|--------------|-----|---------|--|
| 2CH | 5CH | | |
| 1 | 1 | 0-255 | Cool-White (0-Black , 255-100% Cool-White) |
| 2 | 2 | 0-255 | Warm-White (0-Black , 255-100% warm-White) |
| | 3 | 0-10 | No function (shutter open) |
| | | 11-50 | No function (shutter open) |
| | | 51-90 | Color_temperature(3200K) |
| | | 91-130 | Color_temperature(4300K) |
| | | 131-170 | Color_temperature(5600K) |
| | | 171-210 | Color_temperature(6500K) |
| | | 211-250 | Color_temperature(7200K) |
| | | 251-255 | No function (shutter open) |
| | 4 | 0 | No function (shutter open) |
| | | 1-95 | Strobe effect slow to fast |
| | | 96-127 | No function (shutter open) |
| | | 128-159 | Pulse-effect in sequences |
| | | 160-191 | No function (shutter open) |
| | | 192-223 | Random strobe effect slow to fast |
| | | 224-255 | No function (shutter open) |
| | 5 | 0-255 | Dimming (0-Black , 255-100%) |