



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

Color Chorus 12 Parts List

Item	Description
5040000017	24V 8.3A POWER SUPPLY FOR DW CHORUS 12
5050100034	15 DEGREE LENS FOR COLOUR CHORUS 24, COLOUR CHORUS 48
5050100035	8 DEGREE LENS FOR COLOUR CHORUS 24, COLOUR CHORUS 48
5060500028	SOI DOUBLE END LED CABLE FOR COLOUR CHORUS UNITS
606040005	KSD301 250V 10A 90 DEG THERMOSTAT FOR COLOUR CHORUS 12
7010201060A	SOI RIGHT BRACKET FOR COLOUR CHORUS 12
7010201061A	SOI LEFT BRACKET FOR COLOUR CHORUS 12
801001301	3PIN XLR PCB FOR COLOUR CHORUS 12
8010021801	5PIN XLR PCB FOR COLOUR CHORUS 12
8010040400	LARJ45-03A ETHERNET PCB FOR COLOUR CHORUS 72
8010046900	TEMPERATURE CONTROL PCB FOR COLOUR CHORUS 23 (LA4121-04A-001)
8010053200	L20104-03B LED PCB FOR COLOUR CHORUS 12
8010054900	L20103-04B PCB FOR COLOUR CHORUS 12
8020000250	WIRE HARNESS FOR COLOUR CHORUS 12
8060034600	LAETMO-01A PCB FOR COLOUR CHORUS 12
8061034600	L20103-02C DISPLAY PCB FOR COLOUR CHORUS 12
ESD0008-B	BLUE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60
ESD0008-W	WHITE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60,
LA-WG-004	DISPLAY COVER FOR CUEPIX PANEL, CUEPIX STRIP TRI
LA2115-L-13	BRACKET ADJUSTER FOR COLOUR CHORUS 24
M5-08X30	TRUNNION SCREW FOR COLOUR CHORUS SERIES