



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

Color Chorus 48 Parts List

Item	Description
501000012	DFM8015B FAN FOR COLOUR CHORUS 72, COLOUR CHORUS 48
504000016	24v 8.3A POWER SUPPLY FOR COLOUR CHORUS 72, COLOUR CHORUS 48
504000099	24V 16.7A POWER SUPPLY FOR COLOUR CHORUS 24
5050100034	15 DEGREE LENS FOR COLOUR CHORUS 24, COLOUR CHORUS 48
5050100035	8 DEGREE LENS FOR COLOUR CHORUS 24, COLOUR CHORUS 48
5060500028	SOI DOUBLE END LED CABLE FOR COLOUR CHORUS UNITS
6060400000	KSD301 250V 10A 90 DEGREES THERMOSTAT FOR COLOUR CHORUS 24
7010200908	SOI FAN GRILL FOR COLOUR CHORUS 48
7010200911A	SOI SUPPORTING FOOT FOR COLOUR CHORUS 24, DW CHORUS 48
7010200912A	SOI SIDE PLATE FOR COLOUR CHORUS 24
7030100111A	SOI LENS HOLDER FOR COLOUR CHORUS 24
7030100112	SOI LENS BASE PLATE FOR COLOUR CHORUS 24
8010000968	LADMX-10A J3 3PIN/5PIN XLR OUT PCB FOR CUEPIX PANEL W/ARNET
8010046400	LED PCB FOR COLOUR CHORUS 24, COLOUR CHORUS 72 (L20104-03B)
8010046501-245	LAETMO-01A MAIN PCB FOR COLOUR CHORUS 48
8010046700	LA2115-06B JUMPER PCB FOR COLOUR CHORUS 24
8010046900	TEMPERATURE CONTROL PCB FOR COLOUR CHORUS 23 (LA4121-04A-001)
8020000239	WIRE HARNESS FOR COLOUR CHORUS 48
810000974	J3 & J4 3PIN/5PIN XLR IN PCB FOR CUEPIX PANEL (WITH ARTNET)
ESD0008-B	BLUE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60
ESD0008-W	WHITE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60
LA-WG-004	DISPLAY COVER FOR CUEPIX PANEL, CUEPIX STRIP TRI
LA2115-L-13	BRACKET ADJUSTER FOR COLOUR CHORUS 24
LARJ45-03A	LARJ45-03A RJ45 PCB FOR CUEPIX BATTEN, CUEPIX PAR 300
LCD-3118	DISPLAY BUTTON FOR CUEPIX BLINDER WW4
M5-08X30	TRUNNION SCREW FOR COLOUR CHORUS SERIES
P-CON CABLE 16G	AWG POWER CABLE W/POWER CON
P000000352	DISPLAY PCB FOR COLOUR CHORUS 48 (LONG TACT SWITCH)
P000000710	SOI LEFT BRACKET ASSEMBLY FOR COLOUR CHORUS 24
P000000711	RIGHT BRACKET ASSEMBLY FOR COLOUR CHORUS 24,48 & 72
P000001388	DISPLAY PCB FOR COLOUR CHORUS 48 (SHORT TACT SWITCH)



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM