



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

Full Boar 4 Parts List

Item	Description
80320021	ARMREST
90709150	ARMREST SCREW
80450111	BEZEL, LEFT SIDE
80450110	BEZEL, RIGHT SIDE
91000306	BEZEL, SCREWS
25090010	BUTTON, FLASH
25090011	BUTTON, STANDARD
90409536EF	CABLE, BACKLIGHT ASSEMBLY, 2 PER CONSOLE
90409542EF	CABLE, CAT 5, 1'
25091402	CABLE, DESKLIGHT, INCLUDES XLR CONNECTOR
90409544EF	CABLE, DISPLAY, LEFT
90409540EF	CABLE, DISPLAY, RIGHT
90409532EF	CABLE, DVI ADAPTER, ACTIVE
90409543EF	CABLE, DVI ADAPTER, PASSIVE
90409517EF	CABLE, DVI-D, 18"
90409541EF	CABLE, SATA 20"
90409514EF	CABLE, USB A TO 5 PIN
90409511EF	CABLE, USB DISPLAY
90409512EF	CABLE, USB PANEL MOUNT, USB PORT AT TOP OF THE CONSOLE
90409279	CABLE, USB PANEL MOUNT, 2 USB PORTS ON REAR OF CONSOLE
90409515EF	CABLE, USB PLAYBACK PCB
90409513EF	CABLE, USB PROGRAM PCB
61100004	DESK LIGHT, 18"
90306202EF	DISPLAY / TOUCHSCREEN, 15.6"
61080009	Dust Cover
B372714 E	ENCODER
90724016	ENCODER BUTTON, SMALL GRAY OVAL BUTTONS
90410167	ENCODER WHEEL, FOR 4 ENCODERS
90405313EF	FADER, MOTORIZED
90405336EF	FADER KNOB, CONDUCTIVE
91240308	FADER SCREW
80270043EF	FAN ASSEMBLY



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

90903058EF	HARD DRIVE, SSD 20GB 2.5"
90409516EF	HARNESS, 12V EXTENDER, POWER SUPPLY TO PROGRAM PCB
90409321EF	HARNESS, ETHERNET LED
90409452EF	HARNESS, LED STRIP DOUBLE, LEFT AND CENTER LED STRIP
90409451EF	HARNESS, LED STRIP SINGLE, RIGHT LED STRIP
90409307EF	HARNESS, LTC / MIDI
90409207	HARNESS, POWER SUPPLY TO DISPLAYS, 6" ADAPTER
90409477EF	HARNESS, TRACKBALL
90411093	HEATSINK AND FAN
80060019EF	LED, 12 LED KEYBOARD STRIP, 2 PER CONSOLE
80060042EF	LED, 9 LED STRIP, 1 PER CONSOLE
99090109	LED LENS, CLEAR, 33 PER CONSOLE
99090110	LED LENS, RETAINING RING, 33 PER CONSOLE
90409529EF	LED STRIP, BLUE REAR VENT LEDS
99263138	LED STRIP, MOUNT FOR BLUE VENT LEDS
80060029EF	PCB, 4/5 LED FLEX
80030097EF	PCB, DMX OUTPUT X 4
80030089EF	PCB, ETHERNET
80430159	PCB, MOTHERBOARD ASSEMBLY
80030096EF	PCB, MIDI IN/OUT/THRU
80040050EF	PCB, PLAYBACK ASSEMBLY
80040048EF	PCB, PROGRAM ASSEMBLY
80030099EF	PCB, TIMECODE
90902067EF	PCB, VIDEO CARD
90803038EF	POWER CABLE, 6'
99070019EF	POWER SUPPLY
90903069	RAM
61070010	ROAD CASE
90724020EF	TRACKBALL
90724017	TRACKBALL BUTTON, LOWER LEFT / UPPER RIGHT
90724018	TRACKBALL BUTTON, UPPER LEFT / LOWER RIGHT
90903067	USB FLASH DRIVE, 2GB, HOG, BLACK
90903068	USB FLASH DRIVE, 2 GB, RESTORE, RED



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM