



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

LEDWash 600+ Parts List

Item	Description
11010490	Spring ring D46 d32 Th.0,32
11013519	Underlay of front panel
11013524	Grounding of arm of axe Y right
11013525	Grounding of arm of axe Y left
11013528	Toothwheel D40
11013529	Holder of stepper motor X
11013530	Holder of axe X on base
11013531	Movement-stop X
11013541	Holder of LED lens FCM-35A-0R RBX 35mm MC
11013593	Washer D16 d8
11013629	Locking (sheet metal)
12010182	Spacer D6xL7 M2
12010198	Spacer D6xL4,5 M3
12010202	Spacer D6xL9 M2
12020018	Spacer D6xd3,8xL4
12040101	Toothwheel RPP3-03 D11 z12
12040102	Toothwheel D66 (inner diameter 16)
12050561	Holder ball-bearing
12050562	Pivot X axe 2
12050563	Ring-plastic
12050564	Screw socket head cap M5x10 (stopper)
12050565	Holder ball-bearing
12050566	Insert of ball bearing
12050567	Pivot of ball bearing
12050568	Stopper hexagon SW7 L8 M4
12050593	Nut of stopper SW7 M4
12050609	Teflon housing
12050610	Interposer bar
12050645	Spacer hexagon



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

13020050	Power supply 48V/400W, 90-264V
13030149	PCB CNG-4 version H
13030152	PCB EZ1051
13030760	PCB DMX Connectors RB2530
13030761	PCB MH-1
13030763	PCB RB2550 37 CREE-MCE
13030778	PCB RB2006 Robin 600 LEDWash M
13030780	PCB Display QVGA Robin 600 LEDWash DS
13030782	PCB Con2E
13030822	PCB MH-2
13031061	PCB Display QVGA Robin 600 LEDWash Wifi DS
13031194	PCB RB8051, 37 SW Ostar
13031199	PCB RB8051-A 7 Ostar
13031200	PCB RB8051-B 12 Ostar
13031201	PCB RB8051-C J3 9 Ostar
13031202	PCB RB8051-C J4 9 Ostar
13031332	PCB RB2511 Robin 600+ LEDWash L
13031607	PCB RB2511 Robin 600+ LEDWash SW L
13032137	PCB RB8051-A 7 SW Ostar
13032138	PCB RB8051-B 12 SW Ostar
13032139	PCB RB8051-C J3 9 SW Ostar
13032140	PCB RB8051-C J4 9 SW Ostar
13050070	Cable grommet F0705SR-6R3
13050103	Fuse socket - FPG1
13050171	Terminal end 7610-03/04
13050465	Fuse T 4A ceramic
13051228	Microswitch SM 05L04B-Z
13051408	Spade terminal 4,8
13171192	Wires set f. Robin 600 LEDWash 230/120V Power
13171225	Wires set f. R 600 LEDWash + without Power-wires
14060288	LED lens FCM-35A-0R RBX 35mm MC



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

14060289	LED lens FXLL-35A-A 35mm MC-
16010033	Steppermotor 17HC2001-01N 4A
16010034	Steppermotor LINEAR ACTUATOR 19542-05-001
16010036	Steppermotor LINEAR ACTUATOR/600
16030038	Fan KD1209 PTBX 92x92x25 12V
16030044	Fan KD1206 PHB1 60x60x15
17010008	Ball bearing 6806-ZZ
17010009	Ball bearing 6905-2RS
17010015	Ball bearing 625 2ZR-CMB SRI-2
17020010	Belt 420 RPP3/06
17020031	Belt HTD 03M-267
17030005	Lock ring No.:25
17030016	Rubber base GF2
17030028	Cube self-adhesive F0505 HC-101
17030578	O ring 6x1,5
17030627	Gasket 31010-0 PE 15x10
17030628	O ring 2,9x1,78
17040672	Base plate with nuts Camloc
17040675	Grounding of axe X with nuts
17040677	Grounding for holder of steppermotor
17040679	Holder of axe X B with nuts
17040680	Holder of switch
17040803	Stiffener of arm with nuts
17050322	Holder of axe X with nuts AVDEL
17050324	Holder of axe Y (Steppermotor) with nuts
17050325	Rear panel with nuts
17050326	Side panel with nuts
17050327	Holder of axe Y (switch) with nuts
17050401	Front panel with nuts
18010003	Screw crosswise cup headed M2x3
18010004	Screw socket head cap M4x10
18010007	Screw f. adjusting hexagon socket M4x5



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

18010008	Screw crosswise cup headed M3x8
18010010	Screw crosswise cup countersink M4x14
18010013	Screw socket head cap M4x25
18010016	Screw crosswise cup headed M3x6
18010023	Screw socket head cap M5x10
18010032	Screw crosswise cup countersink M3x8
18010033	Screw crosswise cup countersink M3x6
18010035	Screw crosswise cup countersink M4x8
18010037	Screw crosswise cup headed M4x10
18010038	Screw crosswise cup headed M3x18
18010040	Screw crosswise cup countersink M4x25
18010042	Screw socket head cap M6x20
18010045	Screw crosswise cup countersink M4x35
18010054	Screw crosswise cup headed M3x10
18010055	Screw crosswise cup headed M3x25
18010060	Screw crosswise cup headed M4x12
18010075	Screw crosswise cup countersink M3x20
18010076	Screw crosswise cup countersink M3x5
18010114	Screw crosswise cup countersink M2x6
18010117	Screw crosswise cup countersink M3x12
18010118	Screw crosswise cup countersink M4x10
18010120	Screw crosswise cup countersink M4x16
18010136	Screw crosswise cup countersink M3x16
18010145	Screw crosswise cup headed M3x5
18010159	Screw countersink inside hexagon M4x10
18010210	Screw crosswise cup headed M2x10
18020002	Screw self-tapping 2,9x9,5
18020009	Screw self-tapping 2,9x6,5
18020016	Screw self-tapping countersink 9,9x6,6
18020021	Screw self-tapping 3,5x13



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

18020063	Screw self-tapping countersink 2,9x6,5
18040001	Nut M4 black
18040003	Nut selflock M5
18040005	Nut M3 black
18040020	Nut selflock M4 silver
18040022	Nut selflock M3 silver
18050001	Washer M3 black
18050002	Washer M4 black
18050003	Washer M4 selflock - black
18050006	Washer M5 selflock - black
18050007	Washer M5 black
18050009	Washer M3 selflock - black
18050010	Washer M4 star - black
18050011	Washer M3 star - black
18060039	Lock ring 3
18510246	Screw crosswise cup countersink M2x5
18540020	Nut selflock M4 silver
18540022	Nut selflock M3 silver
19010326	Cover of arm (plastic)
19010327	Cover of base - grip (plastic)
19020081	Grip ROBE
19040093	Antivibration gripping of fan
19520085	EggCrate Robin 600 LEDWash (black)
19530232	Cooler
99010420	Mounting bracket Omega CL assembled
99013057	Cover of base - assembled
99013063	Axe X - assembled
99013064	Arm of axe Y - stepper motor
99013065	Arm of axe Y - switch
99013094	LED module - lens FXLL-35A-A 35mm MC-
99013095	LED module - lens FCM-35A-0R RBX 35mm MC
99013139	Top Hat Robin 600 LEDWash



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

99013174	Arm of axe Y - PCB
11013523-01	Stiffener of arm
11013524-01	Grounding of arm of axe Y right
11013525-01	Grounding of arm of axe Y left
11013530-01	Holder of axe X on base
11013536-02	Holder of stepper motor
11013537-01	Key for axe Y
11013537-02	Key for axe Y
11013539-02	Holder of LED lens FXLL-35A-A 35mm MC-
11013539-05	Holder of LED lens FXLL-35A-A 35mm MC-
11013541-02	Holder of LED lens FCM-35A-0R RBX 35mm MC
11013563-01	Covering of plexiglass
11013595-01	Positioning wheel
11030501-02	Cover of base
12040100-01	Toothwheel D66 (inner diameter 32)
12050562-01	Pivot X axe 2
12050563-01	Ring-plastic
12050567-01	Pivot of ball bearing
12050571-01	Extension of stepper motor 600
13030760-01	PCB RB2530-V2 DMX connectors
13031112-02	PCB RB8051 37 Ostar
14060283-01	Cover plexiglass
14060283-02	Cover plexiglass
14060283-03	Cover plexiglass
14060288-03	LED lens FCM-35ASG-0R RBX 35mm MC
14060289-01	LED lens FXLL-35AHT-A 35mm MC-
14060289-02	LED lens FXLL-35AHT-A 35mm MC-
17010008-01	Ball bearing 6806-ZZ
17040672-01	Base plate with nuts Camloc
17040675-01	Grounding of axe X with nuts
17040676-02	Covering of power supply
17040679-01	Holder of axe X B with nuts
17040691-01	Holder of PCB with nuts



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

17050324-01	Holder of axe Y (Steppermotor) with nuts
17050327-02	Holder of axe Y (switch) with nuts
19010325-02	Cover of head (plastic)
19010325-03	Cover of head (plastic)