



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

Mac 575 Krypton Parts List

Item	Description
02121014	6204 Driver Chip
02121015	6205 Driver Chip
04030082	80uF Capacitor w/ Plugs
04401102	Magnet (All Effect Wheels)
04541530	Ballast (Magnetic)
05020025	Fuse, 10A (Mains In)
05031004	Fuse Holder Assembly (Mains In)
05040039	110° Thermosensor
05221209	Lamp Socket
05520503	Microswitch (Pan)
05520503	Microswitch (Lamp Door)
05520504	Microswitch (Focus)
05520506	Microswitch (Tilt)
05701602	Motor (Iris, Prism Rotate)
05701603	Motor (Gobo Rotate)
05701606	Motor (Prism In/Out)
05701610	Motor (Shutters)
05701611	Motor (Gobo 1,Gobo 2,Col 1,Col 2,Zoom,Focus)
05701804	Motor (Pan)
05701804	Motor (Tilt)
05801001	3V Lithium Battery (Main PCB)
06020029	Starter
06150006	SMPS
08052701	M3 Lock Nut (Holds Main PCB to Plate)
08070502	screw (Base Covers - Top)
08111214	M6x30mm Allen Screw (Wheels to Case)
08240107	1/4 Turn Retaining Ring (Head Cover)
08240113	1/4 Turn Wingbolt (Omega Bracket)



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

08240114	1/4 Turn Retainer (Omega Bracket)
08240127	1/4 Turn Receptacle (Head Cover)
08240134	1/4 Turn Stud (Head Cover)
08240135	1/4 Turn Spring (Head Cover)
08240609	Butterfly Latch
11521017	Mains Cable
16040050	Belt (Pan)
18400030	Optical Encoder Wheel (PanFB)
55245018	Cover (Base Top - w/ Film)
55245019	Cover (Base Top - w/ Label)
62000093	Display PCB
62000140	Main PCB
62000144	Inrush/Relay PCB
62003013	Temperature Sensor (Base -BTER)
62003015	Optical Sensor (Pan FB)
62004624	xLR PCB (3P/5P - M/F)
62006021	Mains Filter PCB
62011514	Power Supply PCB (DC-DC)
62222082	Fans (Base)
16040240	belt (Focus Short)
16040250	Belt (Focus Long, Zoom)
16040430	belt (F. Gobo, R. Gobo, Gobo Rotate, Color 1)
16040440	Belt (Prism In/Out)
16040470	Belt (Color, Prism Rotate)
16040510	Belt (Iris)
17300020	plastic Adaptor for Color Filters
17760380	Conical Spring for Gobos
20800170	Air Filter
41002090	Reflector
41102070	Heat Filter (Glass Only)



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

41203020	Lensgroup 1 (Front Lens)
41203025	Lensgroup 2 (Zoom Lens)
41203030	Lensgroup 3 (Focus Lens)
41500026	Iris
55240003	Cover (Main Head w/ 1/4 Turns)
62003019	Hall Sensor (Color 2, Fixed Gobo)
62003020	Hall Sensor (Gobo Rotation)
62003025	Hall Sensor (Rot. Gobo Wheel)
62003029	Temp Sensor (Lamp)
62003032	Hall Sensor (Color 1)
62003036	Microswitch PCB (Zoom)
62222049	fan (Gobo Module - Both are the Same)
62323038	Heat Filter Module (Assembled)
62325093	Shutter Blade (Universal)
62325121	Fixed Gobo Wheel w/ Gobos
62325122	4 Facet Prism in Adaptor
62326079	Color Wheel 1 w/ Colors
62326080	Color Wheel 2 w/ Colors
62326087	Rotating Gobo Wheel w/ Gobos
62400319	Rotating Gobo Guide w/ Bearings
62400506	Fan Assembly (Lamp Section-Pair)
11860089	wireset (Yoke to Head - 1/2/3)
11860212	Wireset (Yoke to Head - Zoom/Focus)
16040090	Belt (Tilt)
18400030	Optical Encoder Wheel (Tilt FB)
55225627	Cover (Arm)
55225704	Cover (Arm with Tilt Lock)
62003008	Optical Sensor (Tilt FB)
19400060	Castor (Wheel)
34204023	Foam (Yoke - Side - 1 pc)



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

- 34204064 Foam (Lid and Top - Base Support - 2 pcs)
- 34204066 Foam (Bottom - Front Lens Support - 1 pc)
- 97010230 Replacement Lamp - GE CSR575/S/DE/70
- 91602001 Omega Bracket
- 91602008 Omega Bracket (T-Shaped)
- 91510020 Flightcase (Empty)