



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

Mania SCX-700 Parts List

Item	Description
04000302	20uF Capacitor
04401102	2x2x2mm Magnet (Gobo, Gobo Rotate, Color)
04503513	Transformer
04540024	Ballast
05020043	Fuse (3.15AT - Mains In - 20x5mm)
05040038	100° Thermostat
05701206	Motor (Gobo)
05701603	Motor (Color)
05701604	Motor (Pan, Gobo Rotate)
05701625	Motor (Shutter)
05701658	Motor (Tilt)
08072310	Finger-Screw for Main Cover
08112305	Handwheel for Mounting Bracket
16040280	Belt (Color)
18260290	Starter
41002093	Reflector
41102061	Heat Filter (Glass Only)
55430045	Mirror w/ Bracket
55430046	Shutter Assembly
55430322	Mounting Bracket
55430333	gobo Guide w/ Bearings
55430335	Color Wheel
55430336	Gobo Wheel
62000119	Hall Sensor (Gobo, Color)
62000124	Main PCB
62000508	Display PCB
62003037	Hall Sensor (Gobo Rotate)
62020080	Power PCB
62222068	Fan w/ Plug
97010111	replacement Lamp - Philips CDM-150 SA/T



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

97010117	Replacement Lamp - Philips MSD-150/2
11820008	XLR Cable, 3Pin Male to 3Pin Female (16.4 Ft)
11501501	Mains Power Cable (IEC to Edison)
90430084	Mania SCX-700 (EU 220-240V)
90430085	Mania SCX-700 (US 110-120V)