



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

RUSH MH 4 Beam Parts List

Item	Description
50480529	Optical orientation plate
50480558	Hall-element board F
50480565	POWERCON socket
50480566	POWERCON socket
50480608	Fuse holder
50480615	Lens Cover
50480616	Lens for MH 4
50480617	Slide rod
50480618	Lens pos sensor PCB
50480619	Lock Safety Wire
50480620	Prisme holder with Prisme
50480621	Head cover with logo
50480622	Gobo Wheel MH 4
50480623	Shutter
50480624	Shutter belt
50480625	Step motor for shutter
50480626	Lamp MH 4
50480627	Thermal switch
50480628	Fan for lamp MH 4
50480629	Shutter
50480630	Fan MH 4
50480631	Colorwheel for MH 4
50480632	Spacer for cover 3 pcs
50480633	Step motor Color wheel
50480634	Step motor MH 4
50480635	Step motor MH 4 prisme
50480636	Prisme belt
50480637	Focus motor MH 4
50480639	Front and rear plate
50480640	Back plate MH 4
50480641	DMX board
50480643	Fan for PSU MH 4



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

50480644	Side plate for MH 4
50480645	Ballast MH 4
50480646	Handel MH 4
50480647	Display assembly MH 4
50480648	PSU for MH 4
50480649	Fast-locking clamp with insert MH 4
50480650	Foot pad MH 4
50480651	Net filter for MH 4
50480652	Yoke cover
50480653	Tilt sensor MH 4
50480654	Pan/tilt driver MH 4
50480655	Tilt belt MH 4
50480656	Pan sensor board MH 4
50480657	Driver board MH 4
50480658	Pan motor MH 4
50480659	Spring for pan motor
50480660	Pos board MH 4
50480661	Pan belt MH 4
50480662	Tilt motor for MH 4
50480663	Yoke fan MH 4
50480696	Head cover with logo(air-outlet) MH 4
50480741	Safety wire hook RUSH Wizard