



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

Studio Command Parts List

Item	Description
99360006	BELT PAN
99360046	BELT TILT
80450085	BEZEL FRONT
80450086	BEZEL REAR
80450084	BEZEL TOP BOX
80010102	BOARD 5 PIN XLR
80060014	BOARD LINE FILTER
80010202	BOARD LOGIC
80050059	BOARD MOTOR POWER SUPPLY
99430116	GEAR, WHEEL SEGMENT
90720009	HANDLE
99270068	MOTOR (OPTICAL MODULE)
99270035	MOTOR (PAN & TILT) (not for 78FAxxxxxxx fixtures)
80570033	OPTICAL MODULE
80010103	SENSOR (ENCODER)
80040019	SENSOR PANT/TILT
80010128	SENSOR TEMP
80200061	WHEEL BEAM
80200058	WHEEL CYAN
80200063	WHEEL DIM/STROBE
80200059	WHEEL MAGENTA
80200060	WHEEL YELLOW
99080264	YOKE COVER
90409240	AC LINE
90409246	LAMP DIMMER CORD
90409242	LAMP HARNESS
80270033	LAMP BLOWER
99150023	LAMP SOCKET
80270034	OPTICAL MODULE FAN
90603011	RELAY
90413012EF	THERMAL SWITCH
80270032	TOP BOX FAN



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

90409240	AC LINE
80270030	FAN OPTICAL MODULE
80060006	IGNITER
80270036	BLOWER HEAD
80050060	BOARD LAMP POWER SUPPLY
99270028	MOTOR PAN & TILT (78FA fixtures ONLY)
80050060	BOARD LAMP POWER SUPPLY
80470218	AC LINE
80050081	BOARD LAMP POWER SUPPLY
90409248	HARNESS IGNITER TO LAMP POWER SUPPLY
90409249	HARNESS IGNITER TRIGGER
90409247	HARNESS LAMP TO IGNITER
80270037	LAMP BLOWER
99150023	LAMP SOCKET
99270035	MOTOR PAN & TILT
80270034	FAN OPTICAL MODULE
90413012EF	THERMAL SWITCH
80270032	TOP BOX FAN
80470219E	F IGNITER