



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

VLZ Wash Parts List

Item	Description
5.01.01.01.11939-A-J0	Axis Sleeve Reinforcing Plate
5.01.01.01.12104-0	Head Guiding Wire Plate
5.01.01.01.13242-0	Washer
5.01.01.01.13243-0-J0	Hook Horizontal Plate
5.01.01.01.13244-0-H0	Hook Plate
5.01.01.01.14065-A-J0	Spring fixed plate
5.01.01.01.14477-0-J0	Pan Orientation Plate
5.01.01.01.14503-A	Motor Base Plate
5.01.01.01.15052-0	Reinforcing Plate
5.01.01.01.15053-A	Central Axis Pressing Plate
5.01.01.01.15055-D-J0	Handle Fixed Plate Welding Assembly
5.01.01.01.15058-A	Mounting Plate for Fixing Plate
5.01.01.01.15061-C-H0	Base Side Plate II
5.01.01.01.15062-A-H0	Fixing Board for Display PCB
5.01.01.01.15063-B	Arm Holder
5.01.01.01.15068-0	Motor Base Plate
5.01.01.01.15070-0-J0	CMY Holder
5.01.01.01.15071-A	Based Plate for adjusting
5.01.01.01.15072-0-J0	Supporting Panel for Adjust Assembly
5.01.01.01.15073-B-J0	Focus Lens Bracket
5.01.01.01.15074-0-J0	Zoom Fixing Board
5.01.01.01.15076-0-J0	Lens Fixing Board
5.01.01.01.15086-0	Fix Base
5.01.01.01.15091	Bucket for Light Source
5.01.01.01.15092-0	Fix Base
5.01.01.01.15109-0-J0	Anti-Dust Net
5.01.01.01.15110-0-J0	Follower Gear
5.01.01.01.15121-0-J0	Positioning Plate
5.01.01.01.15122-A-J0	Fixing Sheet I
5.01.01.01.15123-0	Fixing Board for Motor
5.01.01.01.15124-A-J0	Fixing Board



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.01.01.01.15125-A	Rotating Base Plate
5.01.01.01.15162-0-J0	Plate
5.01.01.01.15230-0	Positioning Plate
5.01.01.01.15465-B	Rotating Plate
5.01.01.01.15470-A	Focus Connection
5.01.01.01.15473-0	Zoom Connection
5.01.01.01.15497-0	Fixing Plate of Motor I
5.01.01.01.15498-A	Fixing Board II for Motor
5.01.01.01.15500-0	Subplate for Light Source
5.01.01.01.15502-A-A0	quick lock Lock Plate
5.01.01.01.15511-0	Pan Lock Bracket Weldment Assembly
5.01.01.01.15513-0-J0	Tilt Limit Brack
5.01.01.01.15516-0-J0	Tilt Limiting Plate Welding Assy
5.01.01.01.15517-A-B0	Color Wheel
5.01.01.01.15518-0-J0	Reinforcing Plate
5.01.01.01.15519-A-J0	Supporting Plate of Pan Wiring
5.01.01.01.15520-0-J0	Pan Motor Board
5.01.01.01.15521-0-J0	Motor Base Plate
5.01.01.01.15522-0-J0	Arm Reinforcing Plate
5.01.01.01.15523-0-J0	Adjusting Plate
5.01.01.01.15524-A	Supporting Plate A of Arm Cover
5.01.01.01.15525-0	Supporting Plate B of Arm Cover
5.01.01.01.15526-A	Limit Bracket
5.01.01.01.15526-A	Limit Bracket
5.01.01.01.15527-0-A0	Side Seal Plate
5.01.01.01.15529-0-J0	Front/Rear Base Cover Connection Parts
5.01.01.01.15558-0	Belt Pressing Plate
5.01.01.01.15602-0-A0	Light Screen Plate
5.01.01.01.15734-A	CMY Holder
5.01.01.01.15736-0	Light Head Base Plate
5.01.01.01.15737-B-J0	Back Seal Plate
5.01.01.01.15739-A-A0	Baffle
5.01.01.01.15760-0-J0	Computer Plug Support Frame



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.01.01.01.15765-A-J0	Fan Mounting Plate
5.01.01.01.15766-0-A0	Arm Cover Fix Plate
5.01.01.01.15767-0-J0	Lock Plate
5.01.01.01.15768-0-J0	Tilt Motor Plate
5.01.01.01.15769-0	Air Shield Board
5.01.01.01.15771-A	Cushion
5.01.01.01.15827-B-J0	Preforming for Belt
5.01.01.01.15834-0-J0	Supporting Panel
5.01.01.01.15840-0-J0	Fixing Board for Magnetic Sensor
5.01.01.01.15841-A-J0	Supporting Panel for Cable
5.01.01.01.15843-0	Air Shield Board
5.01.01.01.15927-A	aluminium axle Fix Block II
5.01.01.01.16016-0-J0	Air Shield Board
5.01.01.01.16159-0-J0	Anti-Dust Net
5.01.01.01.16174-0	Preforming for Belt
5.01.01.01.16289-A-J0	Fixed Plate for Dustproof Cotton
5.01.01.01.16407-0-J0	Fixing Plate II
5.01.01.01.16581-0-J0	Light Shielding Plate
5.01.01.01.16582-0	Subplate for Light Source
5.01.01.01.17039-0	Fan Base Plate
5.01.01.01.17208-0	Cushion II
5.01.01.01.19214-0-J0	drive plate 3
5.01.01.01.5537-0	Tilt Lock Washer
5.01.01.01.8601-B	Pan Position Detection Wheel
5.01.01.01.9107-0-J0	XLR Socket Fixing Board
5.01.01.01.9585-0	Bundle Holder
5.01.02.01.0290-0	Profile Gobo Assembly
5.01.02.03.0028-C	Pulley
5.01.02.03.0051-B	Driving Gear
5.01.02.03.0171-A	Driving Gear
5.01.02.03.0292-A	Pulley
5.01.02.03.0308-A	Tilt Pulley
5.01.02.03.0310-A	Driver Pulley



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.01.02.03.0313-A	Driver Pulley
5.01.02.03.0315-A	Rotating Wheel Assembly
5.01.02.03.0401-0	Driving Gear
5.01.02.03.0411-B	Pan Pulley
5.01.02.03.0486-0	Driving Gear
5.01.02.03.0496-0	Driving Gear
5.01.02.03.0530-0	Driven Wheel Assembly
5.01.02.03.0556-A	Pulley
5.01.02.03.0690-0	Driving Gear
5.01.02.04.0168-A	Slider Assembly
5.01.02.06.0241-0	Rotary Axis
5.01.02.06.0256-C	Tilt Axis Accessory
5.01.02.06.0259-0	Stationary Shaft II
5.01.02.06.0265-A	Central Rotary Axis
5.01.02.06.0302-0	Centre Turning Shaft I
5.01.02.06.0407-A	Drive Shaft
5.01.02.06.0437-A	Tensile Axis Assembly
5.01.02.06.0617-0	CMY Axis
5.01.02.06.0618-0	Tilt Axis
5.01.02.06.0641-0	Igus Al Shaft
5.01.02.07.0091-D-G0	Connecting Pillar
5.01.02.07.0239-A	Tilt Axis Sleeve
5.01.02.07.0276-0	Pressing Roller
5.01.02.07.0425-B	Pan Shaft Sleeve Assembly 1
5.01.02.09.0456-0	Axis Holder
5.01.02.09.1060-0	Positioning Wheel
5.01.02.09.1092-A	Fix Base
5.01.02.09.1186-0	Axis Holder
5.01.02.09.1477-A	Pan Shaft Gasket
5.01.02.09.2123-B	Handle Cushion
5.01.02.09.2129-0-J0	Fixing Pillar
5.01.02.09.2130-0	aluminium axle Fix Block I
5.01.02.09.2132-0	side board Fix Block



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.01.02.09.2135-B-A0	Bottom Board
5.01.02.09.2262-A	Holder
5.01.02.09.2270-A	Tilt Quick Lock
5.01.03.01.0353-C	Optical Sensor Bracket
5.01.03.01.0578-0	Optical Sensor Bracket
5.01.03.01.0674-0	Holder I
5.01.03.01.0675-0	Holder II
5.01.03.01.0676-0	Holder III
5.01.03.01.0677-0	Holder IV
5.01.03.02.0285-A	Belt Cushion
5.01.04.01.0024	Hex Spacer
5.01.04.01.0028	Hex Spacer
5.01.04.02.0022	Hex Spacer
5.01.04.02.0022	Hex Spacer
5.01.04.05.0018	Hex Aluminum Pillar
5.01.04.05.0131	Hex Aluminum Pillar
5.01.04.05.0184	Hex Aluminum Pillar
5.01.04.05.0246-0	Hex Aluminum Pillar
5.01.04.12.0045-0	Round Copper Pillar
5.01.04.12.0049-0	Round Copper Pillar
5.01.04.12.0053-0	Round Copper Pillar
5.01.04.12.0053-0	Round Copper Pillar
5.01.04.12.0059-0	Round Copper Pillar
5.01.04.12.0061-0	Round Copper Pillar
5.01.04.12.0065-0	Round Copper Pillar
5.01.04.12.0068-0	Round Copper Pillar
5.01.04.23.0004	Aluminium Tube
5.01.04.24.0086-A	Square Aluminum Pillar
5.01.04.24.0091-A	Square Aluminum Pillar
5.01.04.24.0092-A	Square Aluminum Pillar
5.01.04.24.0101-A	Square Aluminum Pillar
5.01.04.24.0107-A	Square Aluminum Pillar
5.01.99.01.0007-B	Quick Lock Washer



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.01.99.01.0015-F-G0	Quick Lock Assembly
5.01.99.01.0029-0-G0	Quick Lock Base
5.01.99.01.0073-0	Quick Lock Base
5.02.02.01.4529-103	Half-finished IC Software
5.02.02.01.4530-103	Half-finished IC Software
5.02.02.01.4531-103	Half-finished IC Software
5.02.02.01.4532-103	Half-finished IC Software
5.02.02.01.4533-103	Half-finished IC Software
5.02.02.01.4534-103	Half-finished IC Software
5.02.02.01.4535-103	Half-finished IC Software
5.02.02.01.4536-103	Half-finished IC Software
5.02.03.01.0847	PCB Assembly
5.02.03.01.2561-0-0	PCB Assembly
5.02.03.01.3090-0-0(HY1426)	PCB Assembly
5.02.03.01.3342-0- 0((HY1426)	PCB Assembly
5.02.03.01.3408-0-0	PCB Assembly
5.02.03.01.3433-0-0	PCB Assembly
5.02.03.01.3434-0-0	PCB Assembly
5.02.03.01.3455-0-0(HY1426)	PCB Assembly
5.02.03.01.3456-0-0	PCB Assembly
5.02.03.01.3634-0-0	PCB Assembly
5.02.03.01.3635-0-0	PCB Assembly
5.02.03.01.3803-0-0(HY1426)	PCB Assembly
5.02.03.01.3809-0-0(HY1426)	PCB Assembly
5.02.03.01.3810-0-0(HY1426)	PCB Assembly
5.02.03.01.3824-0-0(HY1426)	PCB Assembly
5.02.03.01.3825-0-0(HY1426)	PCB Assembly
5.02.04.01.0113	Magnetic Sensor
5.02.04.01.0113	Magnetic Sensor
5.02.04.01.0128	Magnetic Sensor
5.02.04.01.0128	Magnetic Sensor
5.02.04.01.0136	Magnetic Sensor
5.02.04.01.0142	Magnetic Sensor



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.02.04.04.0081	XLR Female Socket Assembly
5.02.04.04.0082	XLR Male Socket Assembly
5.03.01.01.1194-A	Wire-passing Ring
5.03.01.01.1309-A	Wire-passing Ring
5.03.01.01.1309-A	Wire-passing Rin
5.03.01.01.1716-A-N0	Front/Rear Base Cover
5.03.01.01.1717-A-N0	Side Cover
5.03.01.01.1718-A-N0	Right Arm Cover
5.03.01.01.1719-A-N0	Left Arm Cover
5.03.01.01.1720-0-N0	Lens Ring
5.03.01.01.1740-A-N0	lighting Head Cover
5.03.01.01.1775-A-N0	yoke top cover
5.03.01.01.1776-A-N0	arm front cover
5.03.01.01.1777-A-N0	rear yoke cover
5.03.01.02.0064-0-N0	Handle
5.03.01.99.0182-0	Positioning Plate Cushion
5.03.01.99.0229-A	batteries Battery Fixing Plate
5.04.01.02.0108	Rotating Prism Wheel Assembly
5.04.01.04.0098	frost assembly 2
5.04.01.04.0099	frost assembly 1
5.04.01.08.0334	Color Wheel Assembly
5.04.01.08.0335	Color Wheel Assembly
5.04.01.09.0586	Magenta CMY Assembly 1
5.04.01.09.0587	Magenta CMY Assembly 2
5.04.01.09.0588	Cyan CMY Assembly 1
5.04.01.09.0589	Cyan CMY Assembly 2
5.04.01.09.0590	Yellow CMY Assembly 1
5.04.01.09.0591	Yellow CMY Assembly 2
5.04.01.09.0592	CTO Color Filter 1 Assembly
5.04.01.09.0593	CTO Color Filter 2 Assembly
5.05.01.01.0848	Base Box Assembly
5.05.01.02.0351	Base Plate Assembly
5.05.01.04.0874	Side Plate Assembly



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

5.05.01.04.0875	Side Plate II Assembly
5.05.01.05.0290	Pan Bracket Assmby
5.05.01.06.0373	Arm Assembly
5.05.01.08.0240	Left Arm Assembly
5.05.01.09.0262	Right Arm Assembly
5.05.01.10.0983	Head Assy
5.05.01.11.0416	Rear Head Assembly (Lamp Base Assembly)
5.05.01.15.1095	Motor Bracket 1 Assembly (CMY Assembly)
5.05.01.15.1096	Motor Bracket 2 Assembly (Pattern Bracket Assembly)
5.05.01.15.1097	Motor Bracket 4 Assembly (Front Head Assembly)
5.05.01.15.1125	Motor Bracket 3 Assembly (Profile Assembly)
5.05.01.99.0110-0	Safety Cable Assembly
6.01.05.04.0157	H Type Crossed Slot Countersunk Head Screw
6.01.05.91.0031	Circlip for Shaft
6.01.05.92.0020-0	Conical Coiled P
6.01.05.92.0021-0	Cylindrical Coiled Pressing Spring (YIII)
6.01.05.92.0067-A	L12 Type Pulling Spring
6.01.05.92.0070-A	L12 Type Pulling Spring
6.01.05.92.0133-B	spring(left)
6.01.05.92.0168-0	Torsional spring
6.01.06.04.0246	Screw
6.01.06.99.0022	Slip Hook
6.01.06.99.0044	circle gel pillar
6.01.06.99.0046	circle gel pillar
6.02.02.01.0009	Belt
6.02.02.01.0014	Belt
6.02.02.01.0075	Belt
6.02.02.01.0081	Belt
6.02.02.01.0137	Belt
6.02.02.01.0332	Belt
6.02.02.01.0355	Belt
6.02.02.01.0392	Belt
6.02.02.01.0457	Belt
6.02.02.01.0542	Belt



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

6.02.02.02.0002-B	Machine Leg
6.02.02.04.0071-A	Quakeproof Rubber
6.02.02.04.0182-0	Rubber Mat
6.02.02.06.0005-0	Rubber Sleeve
6.03.02.01.0128-A	Fixed Lens Assy
6.03.02.01.0129	Zoom Lens Assy
6.03.02.01.0130	Focusing Lens Assembly
6.03.05.03.2468	Color Filter
6.03.05.03.2470	Color Filter
6.03.05.03.2471	Color Filter
6.03.05.03.2472	Color Filter
6.03.05.03.2473	Color Filter
6.03.05.03.2474	Color Filter
6.03.05.03.2475	Color Filter
6.03.05.03.2476	Color Filter
6.03.05.03.2477	Color Filter
6.03.05.03.2619	Color Filter
6.03.05.03.2620	Color Filter
6.03.05.03.2621	Color Filter
6.04.05.03.0337	LED Moudle
6.04.10.01.0071	Stepping Motor
6.04.10.01.0097	Stepping Motor
6.04.10.01.0106	Stepping Motor
6.04.10.01.0116	Stepping Motor
6.04.10.01.0117	Stepping Motor
6.04.10.01.0117	Stepping Motor
6.04.10.01.0138	Stepping Motor
6.04.10.01.0147	Stepping Motor
6.04.10.01.0203	Stepping Motor
6.04.10.01.0286	Stepping Motor
6.04.11.04.0313	Power Supply
6.04.12.04.0065	Power Socket
6.04.12.17.0004	Fuse Tube Holder



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

6.04.12.19.0040	Wiring Pillar
6.04.12.99.0035	Wire Harness Fixing Button
6.04.16.01.0017	Blower
6.04.16.02.0099	DC Fan
6.04.16.02.0164	DC Fan
6.04.16.02.0164	DC Fan
6.04.17.01.0013	High-temperature Resistant Magnet
6.04.17.01.0014	High-temperature Resistant Magnet
6.04.19.01.0219-0	Radiator
6.04.20.03.0014	Fuse
6.04.20.05.0009	High temperature resistant rechargeable lithium
6.04.21.01.0031	Audion Insulating Cap
6.07.01.06.0069-A	Anti-Dust Cotton for Base
6.07.01.06.0070-0	Anti-Dust Cotton for Base 2
6.07.01.99.0027-0	Cable Clip