



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

W-515 Parts List

Item	Description
W-515-H	HEATER FOR W-515
C02009000	RUBBER KEYPAD FOR F-3, W-515
C04312600	/*/*USE ESD0008-B SOCKET FOR DNG-200, W-515
DMX3P12C5	3PIN XLR PCB FOR W-515, W-530E
DMX5P16C5	5PIN XLR PCB FOR W-515
PA0EX7A10	M12070 110V PUMP FOR X-310, DNG-200
PCBS13290	SENSOR PCB FOR Z-350
PCBS23150	/*/*USE PCBS13290 INFRARED RAY LIQUID SENSOR PCB FOR F-3
TKC8C17AA	/*/*USE TKC8C22AA FLEX LOOM/CAP FOR ICE, Z-1500II
TKC8C22AA	FLEX LOOM/CAP FOR ICE, Z-1500II
W-1A	315 MHz WIRELESS RADIO TRANSMITTER FOR W-1 (ORANGE LED LIGHT)
W-1E	433MHz Transmitter for original IP-1500 only
W-515-CP	SOI COPPER TUBE FOR W-515
W-515-PCB	MAIN PCB FOR W-515
W-515-PCBC	CONTROL PCB FOR W-515
W-515-TKC	/*/*/USETKC8C22AA TANK CAP, HOSE & FLUID SENSOR FOR W-515