



2507 HOWARD LANE, AUSTIN, TX 78728

WWW.LIGHTPARTS.COM

ZCL 360i Parts List

Item	Description
Z-500/GMA	10A 250V AC MIDGET FUSE HOLDER FOR DESIGN SPOT 250, DESIGN WASH LED 6
17HC1001Y-25	MOTOR FOR ACL 360I
25PM101-2A4	MOTOR FOR ZCL 360I
5010000037	12vDC 0.20A FAN FOR ZCL 360I
5040000013	K18N-UP200D12 28VDC 3.0A POWER SUPPLY FOR ACL 360I
5040600003	LITHIUM BATTERY FOR ACL 360I, FUZE WASH Z350, FUZE WASH Z350CW
7010500712	SOI ANCHOR WHEEL FOR ACL 360I, FUZE WASH 575, FUZE WASH Z350, FUZE WAS
7010501226	SOI MOUNTING PLATE FOR ACL 360I
7021600004	SOI BRACKET INSERT FOR ACL 360 BAR
7030000000	RUBBER FOOT FOR ACL 360 MATRIX
70300000028	HTD342-3M TILT BELT FOR ACL 360I
70300000029	HTD225-3M PAN BELT FOR ACL 360I
7030100177	BASE COVER FOR ACL 360I
7030100178	HEAD COVER FOR ACL 360I, ZCL 360I
7030100180	ARM COVER FOR ACL 360I
7030100181	MIDDLE COVER FOR ACL 360I
7030100225	LENS COVER FOR ZCL 360I
7050000110	SOI PAN GEAR FOR ACL 360I
7050000206	SOI TILT GEAR FOR ZCL 360I
8010000943	S70801-05B OPTICAL SENSOR FOR ACL 360I
8010000945	S70802-07 XLR PCB FOR ACL 360I
8010000947	LARJ45-06A NETWORK PCB FOR ZCL 360I, CHORUS LINE 16, SEVEN BATTEN 14
8010001076	S70402-08A TOUCH PCB FOR ZCL 360 BAR, FUZE WASH Z350, FUZE WASH Z350CW
8010001149	S70802-04B POWER ADAPTER PCB FOR ZCL 360I
8010001231	S70901-03A LED PCB FOR ZCL 360I
8010001234	S70803-06A SENSOR FOR ZCL 360I
8010100664	S70803-05D DRIVER PCB FOR ZCL 360I
8010100665	S70801-04A PCB FOR ZCL 360I
8010100666	S70802-02B DISPLAY PCB FOR ZCL 360I
8010100667	LAETM0-01ANETWORK PCB FOR ZCL 360I
8050000008	OLD STYLE BRACKET FOR ACL 360 MATRIX
ESD0008-B	BLUE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60, POWER SPOT 575IE, E
ESD0008-W	WHITE FEMALE RECEPTACLE FOR PZ720A, VBAR 270, PD-60, ELED B48,OPTI QUA