Address Dipswitch 7 off and 8 On for Mode 1

| Channel | Assignment | Range % | Construct Parameter |
|---------|------------------------|---------|--|
| 1 | Pan coarse adjustment | | Position |
| 2 | Pan fine adjustment | | Position |
| 3 | Tilt coarse adjustment | | Position |
| 4 | Tilt fine adjustment | | Position |
| 5 | Color Wheel | Full | Color 1 (open) Half color 1 and 2 Color 2 Half color 2 and 3 Color 3 Half color 3 and 4 Color 4 Half color 4 and 5 Color 5 Half color 5 and 6 Color 6 Half color 6 and 7 Color 7 Half color 7 and 8 Color 8 Half color 8 and 1 Forward spin speed 8 Forward spin speed 7 Forward spin speed 6 Forward spin speed 5 Forward spin speed 3 Forward spin speed 1 Reverse spin speed 1 Reverse spin speed 2 Reverse spin speed 3 Reverse spin speed 4 Reverse spin speed 4 Reverse spin speed 5 Reverse spin speed 7 Reverse spin speed 7 Reverse spin speed 7 Reverse spin speed 7 Reverse spin speed 6 Reverse spin speed 7 Reverse spin speed 8 Color 1 (open) |
| 6 | Cyan (Red) | | Color Mix |
| 7 | Magenta (Green) | | Color Mix |
| 8 | Yellow (Blue) | | Color Mix |

| 9 | Static litho | Full 0 | Litho 1 (open) Litho 2 Litho 3 Litho 4 Litho 5 Litho 6 Litho 7 Litho 8 Forward spin speed 8 Forward spin speed 7 Forward spin speed 6 Forward spin speed 5 Forward spin speed 4 Forward spin speed 1 Reverse spin speed 1 Reverse spin speed 1 Reverse spin speed 3 Reverse spin speed 3 Reverse spin speed 4 Reverse spin speed 6 Reverse spin speed 7 Reverse spin speed 8 Litho 1 (open) |
|----|---------------------------------|-----------|---|
| 10 | Rotating Litho | Full 0 | Position 3 (open) Reverse rotate 5 Reverse rotate 4 Reverse rotate 2 Reverse rotate 1 Forward rotate 5 Forward rotate 4 Forward rotate 2 Forward rotate 1 Position 5 Position 4 Position 3 (open) Position 2 Position 1 Position 3 (open) |
| 11 | Rotate (use with Channel 10) | | For Rotating Litho rotate mode use Ch 11 to set rotation speed For Rotating Litho position mode use Ch 11 to set the index from 0 to 360 degrees |
| 12 | Zoom | | Zoom in/out |
| 13 | Focus | | Focus in/out |
| 14 | Iris | | Iris open/close |
| 15 | Effects Wheel | Full 0 | Effect 4 (open) Effect 8 Effect 7 Effect 6 Effect 5 Effect 4 Effect 3 Effect 2 Effect 1 Effect 4 (open) |
| 16 | Frost | | Frost in/out |

| 17 | Shutter | Full 0 | Open Closed Strobe speed 8 Strobe speed 7 Strobe speed 6 Strobe speed 5 Strobe speed 4 Strobe speed 3 Strobe speed 2 Strobe speed 1 Open Closed |
|-----|-------------|-----------|---|
| 18 | Dim | | Dim open/close |
| 19 | Motor Speed | Full 0 | Speed 99 Speed 1 Speed 94 |
| 20* | Control | | 50% fader – shutdown 25% fader – home |